

**Reconnaissance Study
Columbia River Channel Deepening
Water and Sediment Quality
November 1990¹**

Measures of water quality parameters for priority pollutants tested in the lower Columbia River show values less than the concentration standards set by the Oregon Department of Environmental Quality (DEQ) for the Columbia River. Dissolved solids range from 75 to 112 mg/l; the DEQ standard's 200 mg/l. Below Portland, the dissolved solids content shows a slight decrease because of the dilution effect of tributaries.

Sediment samples for chemical (dioxin/furan and TOC) and physical (grain size and volatile solid) analyses were collected within the proposed channel alignment at various locations along the lower Willamette River (WR) and Columbia River (CR) between May 3, 1990 and May 18, 1990. Sediment samples were collected from 5 general reaches of the two rivers using a Benthos gravity corer. These reaches included Portland Harbor Area (RN 4+10 to RN 11+00) on the Willamette River and Camas (RN 118+26), St. Helens (RN 85+45), Longview (RN 63+00 to RN 65+40) and Wauna (RN 38+00 to RN 43+05) on the Columbia River. Sample locations were chosen from within the project boundaries including the channel and sideslopes where dioxins/furans would be expected to be located if present in the sediments. Along the Columbia River the sample locations were near discharges from pulp and paper mills. In the Willamette River, sample locations were chosen from general shoal areas or where previous sampling had indicated the presence of similar hydrophobic organic compounds (i.e. PCBs, PAHs, pesticides) and where previous analyses by DEQ indicated that dioxins/furans were present.

All samples collected were physically analyzed for grain size and volatile solids. Sediment samples from the Columbia River (those marked CR-... in Table 1) generally range in median grain size from coarse sand to coarse silt. The three (3) notable exceptions to this are CR-GC-2, CR-GC-5 and CR-GC-6 whose median grain size are between a medium to fine silt. Samples CR-GC-2 (from the sideslope of the channel adjacent to the Longview anchorage) and CR-GC-6 (taken from the sideslope of the navigation channel) also show some of the highest percentages of volatile solids and TOC of the samples collected including most of those on the Willamette River. The material was fine grained, stiff and had black to yellowish plant material which ran vertically with the core not in horizontal depositional layers. Further studies are needed for verification, but it is most likely that these samples represent old shallow marsh deposits as they could not have been deposited under the present environmental conditions at the site. The other Columbia River samples have low volatile solids and TOC (less than 1.5% and 1.2% respectively) which are typical of clean sand. Due to the coarseness of the material encountered at those locations so indicated in the table, representative samples of the bottom material could not be collected with the gravity corer therefore analyses could not be conducted.

Sediment samples from the Willamette River (those marked WR-... in Table 2) have median grain sizes in the coarse to medium silt range with the exception of WR-GC-8 which is a fine sand taken from the center of the channel. Volatile solids range from 3.5% to 10.0% while TOC

ranges from 0.90 to 4.0 percent. TOC was lowest in the two (2) cores taken from the center of the channel.

A total of nineteen (19) samples or composites were analyzed for the presence of dioxins/furans using combined capillary column gas chromatography/high resolution mass spectrometry (HRGC/HRMS) monitoring five groups of selected ion masses as described in EPA method 8290. These five groups correspond to the tetrachlorinated through octachlorinated congener classes. Each group contained three (3) ion masses for dioxin (with the exception of TCDD which contained two (2) ion masses), two (2) ion masses for the furans, the corresponding ion masses from two (2) isotopically internal standards and the ion mass characteristic of the polychlorinated diphenylether (PCDPE) which, if present, could cause false responses in the dibenzofuran channels. The third dioxin mass monitored in the pentachloro- through octachlorodibenzo-p-dioxin groups prevent the possibility of misinterpretation of a polychlorinated biphenylene (PCB) isomer as a dioxin. The two (2) ion masses monitored for TCDD also fulfilled this purpose. The mass spectrometer was operated in the electron impact ionization mode at a mass resolution of 10,000-11,000 (N/N, 10 percent valley definition). This resolution is sufficient to resolve most interferences, such as PCBs, thus providing the highest level of confidence that the detected levels of dioxin/furan are not false positives resulting from interferences. In addition, a laboratory method blank using a clean sand was prepared and processed along with each extraction batch (10 samples) as part of the QC/QA procedure. The results of these analyses are presented in Table 3. Negative numbers indicate detection limits for nondetected isomers while ND stands for None Detected.

All of the samples with WR prefixes, with the exception of WR-GC4, were found to contain polychlorinated diphenylethers (PCDPEs), substances which can cause false positive responses for PCDFs. Those PCDF responses having a simultaneous response in the PCDPE ion trace were not included in the quantifications due to the possibility that the furan was an artifact produced from the diphenylether. The reported detection limits for the affected 2,3,7,8-substituted isomers in the samples are, therefore, elevated.

Comparison of the test results with the appropriate laboratory method blank show that CR-GC-4(EPA), CR-GC-5, CR-GC-15, CR-GC17&18, CR-GC-23&24 and CR-GC-25&26 have levels of the affected isomers that were comparable to those found in the blank (background levels). Additionally, the levels determined for the affected furan isomers in sample CR-VC-12A&12B may also have originated from the background.

Though various isomers of dioxin/furan were detected in all of the samples tested many of the individual isomer concentrations found in the Columbia River samples can be attributed to background levels in the analytical system. In addition concentrations found in samples from the Columbia River are orders of magnitude below those found in the Willamette River samples. The isomer 2,3,7,8-TCDD was confirmed in only two (2) of the twenty (20) analyses; WRGC-4 at 0.63 pptr and WR-GC-7Rep at 0.62 pptr. The associated furan isomer, 2,3,7,8-TCDF, was detected at concentrations ranging from a low of 0.73 pptr (WR-GC-7) to a high of 110.0 pptr (WR-GC4) in the Willamette River samples. WR-GC-4 was collected from the Doan Lake area where contamination of DDD, DDT and PAHs have been noted in the past.

Table 4 presents the data in the form of 2,3,7,8-TCDD toxicity equivalence. The numbers are derived by multiplying the detected concentration by its appropriate toxicity equivalency factor (TEF 1989) and correcting for the detected background concentrations.

Most of the research with regard to dioxins/furans has concentrated on the "bad actor" 2,3,7,8-TCDD and little or no information exists on the other congeners. It is generally accepted that the higher weighted dioxins/furans are not as readily taken up or bioaccumulated by organisms and are less toxic. These higher weighted dioxins/furans occur naturally as combustion byproducts from such things as forest fires and wood stoves.

In the Columbia River, from the results of our preliminary investigation, significant dioxin/furan contamination of the sediments within the Columbia River portion of the project is not evident. In the Willamette River, though 2,3,7,8-TCDD and the lower weighted dioxins were found only at low levels, the higher weighted less toxic dioxins and the furans are significantly elevated above background. Further testing and evaluation will be required in this area. Analyses need to be expanded to include other contaminants of concern as well as biological effects based evaluations.

1. The above information is an excerpt taken from the November 1990 Columbia River Channel Deepening Reconnaissance Study, pages D-2 through D-9.

TABLE 1: COLUMBIA RIVER SEDIMENT SAMPLE PHYSICAL PROPERTIES

| SAMPLE SITE | LOCATION | | | | PHYSICAL PROPERTIES | | |
|----------------|------------|---|---|---|-----------------------|---------|-------------|
| | RIVER MILE | L | C | R | MEDIAN GRAIN SIZE(mm) | % FINES | VOL. SOLIDS |
| CR-GC-1 | 65+40 | | | X | See Note | | |
| CR-GC-2 * | 64+00 | | | X | 0.0095 | 89.1 | 11.0 |
| CR-GC-3 | 64+00 | | X | | See Note | | |
| CR-GC-4(EPA) * | 64+00 | X | | | 0.16 | 3.3 | 0.7 |
| CR-GC-5 ** | 63+00 | | | X | 0.016 | 91.9 | 5.5 |
| CR-GC-6 * | 63+00 | X | | | 0.0086 | 92.1 | 9.6 |
| CR-GC-7 | 63+00 | | X | | 0.58 | 0.8 | 0.9 |
| CR-VC-9 | 43+05 | X | | | 0.085 | 39.4 | 0.5 |
| CR-VC-10 | 43+05 | X | | | 0.084 | 39.7 | 0.5 |
| CR-VC-11 | 43+05 | X | | | 0.052 | 70.6 | 1.4 |
| CR-VC-12A ** | 43+05 | X | | | 0.032 | 91.5 | 1.3 |
| CR-VC-12B ** | 43+05 | X | | | 0.059 | 66.5 | 1.4 |
| CR-VC-13 | 43+10 | | | X | 0.29 | 1.5 | 0.6 |
| CR-VC-14 | 43+10 | | | X | 0.3 | 1.5 | 0.6 |
| CR-GC-15 * | 41+00 | | X | | 0.38 | 0.3 | 0.5 |
| CR-GC-16 * | 41+00 | X | | | 0.39 | 0.4 | 0.5 |
| CR-GC-17 * | 39+35 | | | X | 0.5 | 0.3 | 0.6 |
| CR-GC-18 * | 39+21 | | | X | 0.3 | 0.9 | 0.4 |
| CR-GC-19 | 38+00 | | | X | See Note | | |
| CR-GC-20 | 38+00 | X | | | See Note | | |
| CR-GC-21 | 38+00 | | | X | See Note | | |
| CR-GC-23 ** | 85+45 | X | | | 0.33 | 0.3 | 0.5 |
| CR-GC-24 ** | 85+45 | X | | | 0.34 | 0.4 | 0.5 |
| CR-GC-25 ** | 118+25 | | | X | 0.44 | 0.5 | 0.7 |
| CR-GC-26 ** | 118+26 | | | X | 0.32 | 0.4 | 0.8 |
| MINIMUM | | | | | 0.0086 | 0.3 | 0.4 |
| MAXIMUM | | | | | 0.58 | 92.3 | 11 |
| MEAN | | | | | 0.23 | 29.57 | 1.93 |

Note: Unable to collect sufficient gravity core sample due to coarseness of material.

*, **: Samples run with Method Blank 1(*) and Method Blank 2 (**), respectively (Table 2).

TABLE 2: WILLAMETTE RIVER SEDIMENT SAMPLE PHYSICAL PROPERTIES

| SAMPLE SITE | LOCATION | | | | PHYSICAL PROPERTIES | | |
|-----------------|------------|-----------|---------------|---|--------------------------|---------|-------------|
| | RIVER MILE | L | C | R | MEDIAN GRAIN SIZE(mm) | % FINES | VOL. SOLIDS |
| WR-GC-2 ** | 4+13 | X | | | 0.023 | 78.30 | 6.50 |
| WR-GC-3A * | 6+35 | | | X | 0.015 | 88.20 | 8.40 |
| WR-GC-3B * | 6+35 | | | X | 0.014 | 87.60 | 10.00 |
| WR-GC-4 ** | 7+12 | X | | | 0.02 | 88.40 | 7.60 |
| WR-GC-5 * | 9+00 | X | | | 0.031 | 67.00 | 6.90 |
| WR-GC-6 * | 9+00 | | X | | 0.048 | 63.30 | 5.80 |
| WR-GC-7 ** | 9+50 | | | X | 0.037 | 70.30 | 5.20 |
| WR-GC-7Rep ** | 9+50 | | | X | 0.037 | 70.30 | 5.20 |
| WR-GC-8 * | 10+00 | | X | | 0.15 | 19.00 | 3.50 |
| WR-GC-9 * | 9+50 | X | | | 0.062 | 55.50 | 6.40 |
| WR-GC-10 ** | 11+00 | X | | | 0.028 | 76.10 | 7.80 |
| MINIMUM | | | | | 0.014 | 19.00 | 3.50 |
| MAXIMUM | | | | | 0.15 | 88.40 | 10.00 |
| MEAN | | | | | 0.04 | 69.45 | 6.66 |
| * METHOD BLANK | BATCH 1 | 8/08/1990 | NOT AVAILABLE | | | | |
| ** METHOD BLANK | BATCH 2 | 7/23/1990 | NOT AVAILABLE | | | | |

*, **: Samples run with Method Blank 1 (*) and Method Blank 2 (**), respectively.

TABLE 3: Lower Columbia and Willamette River Sediment Sample Dioxin Raw Data (in pptr).

| SAMPLE SITE | TOC | 2378 TCDF | TOTAL TCDF | 2378 TCDD | TOTAL TCDD | 12378 PeCDF | 23478 PeCDF | TOTAL PeCDF | 12378 PeCDD | TOTAL PeCDD | 123478 HxCDF | 123678 HxCDF | 123789 HxCDF | 234678 HxCDF | TOTAL HxCDF | 123478 HxCDD | 123678 HxCDD | 123789 HxCDD | TOTAL HxCDD | 1234678 HpCDF | 1234789 HpCDF | TOTAL HpCDF | 1234678 HpCDD | TOTAL HpCDD | OCDF | OCDD |
|-----------------|-------|-----------|------------|-----------|------------|-------------|-------------|-------------|-------------|-------------|--------------|--------------|--------------|--------------|-------------|--------------|--------------|--------------|-------------|---------------|---------------|-------------|---------------|-------------|----------|-----------|
| CR-GC-2 * | 6.10 | -2.00 | ND | -5.40 | ND | -2.00 | -1.20 | ND | -1.40 | ND | -0.97 | -1.70 | -2.00 | -3.50 | 5.10 | -1.60 | -3.20 | -4.20 | ND | -6.20 | -7.10 | ND | 9.70 | 20.00 | -21.00 | 120.00 |
| CR-GC-4(EPA) * | 0.62 | 0.80 | 1.10 | -0.38 | 3.50 | -0.20 | -0.16 | ND | -0.17 | ND | -0.20 | -0.22 | 0.27 | -0.08 | 0.49 | -0.11 | 0.28 | -0.27 | 1.60 | 0.48 | -0.12 | 1.30 | 2.90 | 5.00 | 0.66 | 25.00 |
| CR-GC-5 ** | 1.60 | 0.37 | 0.37 | -0.32 | ND | -0.13 | -0.13 | ND | -0.17 | ND | -0.11 | -0.29 | 0.28 | -0.12 | 0.28 | -0.18 | -0.23 | -0.31 | 0.93 | -0.25 | -0.65 | ND | 1.30 | 2.80 | -0.67 | 14.00 |
| CR-GC-6 * | 7.50 | 2.00 | 2.00 | -1.50 | ND | 4.10 | 3.60 | 7.70 | 3.80 | 3.80 | 4.50 | 3.80 | 4.10 | 4.20 | 17.00 | 4.50 | 3.50 | 2.30 | 10.00 | 5.40 | 5.50 | 11.00 | 7.10 | 7.10 | 15.00 | 54.00 |
| CR-VC-12A ** | 0.84 | 0.89 | 2.90 | -0.42 | 0.42 | 0.24 | -0.14 | 2.20 | 0.18 | 0.48 | 0.48 | 0.33 | 0.37 | -0.14 | 3.90 | 0.26 | 2.10 | 0.77 | 11.00 | 1.80 | -0.56 | 5.60 | 25.00 | 46.00 | 4.40 | 220.00 |
| CR-VC-12B ** | 0.30 | 0.80 | 0.80 | -0.70 | 2.20 | -0.45 | -0.70 | ND | -0.54 | ND | -0.23 | -0.35 | 0.57 | -0.61 | 0.57 | -1.10 | -0.93 | -0.78 | ND | 0.56 | -0.80 | 1.70 | 2.30 | 4.40 | 3.30 | 29.00 |
| CR-GC-15 * | -0.20 | 0.58 | 1.20 | -0.98 | 0.63 | -0.59 | -0.39 | ND | -0.24 | ND | -0.80 | -0.75 | -1.40 | -1.50 | ND | -0.88 | -0.99 | -1.90 | ND | -0.74 | -3.30 | ND | 3.50 | 5.10 | 0.73 | 30.00 |
| CR-GC-16 * | 0.39 | 1.10 | 1.10 | -0.74 | 3.70 | -0.83 | -0.68 | ND | -1.20 | ND | -0.47 | -0.61 | 0.49 | -0.69 | 0.49 | -0.80 | -1.00 | -0.85 | ND | 0.47 | -0.25 | 1.30 | 4.10 | 11.00 | 1.60 | 53.00 |
| CR-GC-17 * | 1.10 | -0.57 | ND | -0.46 | ND | -0.06 | -0.18 | ND | -0.25 | ND | -0.23 | -0.18 | -0.28 | -0.27 | ND | -0.43 | -0.29 | -0.25 | ND | -0.27 | -0.21 | ND | 1.50 | 1.50 | -0.41 | 8.60 |
| CR-GC-18 * | -0.20 | 0.43 | 0.43 | -0.45 | ND | -0.09 | -0.10 | ND | -0.05 | ND | -0.13 | -0.07 | 0.22 | -0.10 | 0.22 | -0.25 | -0.22 | -0.36 | 0.31 | -0.62 | -0.13 | 0.67 | 2.80 | 5.80 | 0.97 | 45.00 |
| CR-GC-23 ** | | | | | | | | | | | | | | | | | | | | | | | | | | |
| CR-GC-24 ** | | | | | | | | | | | | | | | | | | | | | | | | | | |
| CR-GC-25 ** | | | | | | | | | | | | | | | | | | | | | | | | | | |
| CR-GC-26 ** | | | | | | | | | | | | | | | | | | | | | | | | | | |
| MINIMUM | 0.30 | 0.37 | 0.37 | 0.00 | 0.42 | 0.24 | 3.60 | 2.20 | 0.18 | 0.48 | 0.48 | 0.33 | 0.22 | 4.20 | 0.22 | 0.26 | 0.28 | 0.77 | 0.31 | 0.47 | 5.50 | 0.67 | 1.30 | 1.50 | 0.66 | 8.60 |
| MAXIMUM | 7.50 | 2.00 | 2.90 | 0.00 | 3.70 | 4.10 | 3.60 | 7.70 | 3.80 | 3.80 | 4.50 | 3.80 | 4.10 | 4.20 | 17.00 | 4.50 | 3.50 | 2.30 | 11.00 | 5.40 | 5.50 | 11.00 | 25.00 | 46.00 | 15.00 | 220.00 |
| WR-GC-2 ** | 2.40 | 19.00 | 49.00 | -0.58 | 4.30 | 24.00 | 10.00 | 84.00 | -1.50 | ND | -62.00 | 11.00 | 4.30 | 1.50 | 140.00 | 2.70 | 21.00 | 11.00 | 140.00 | 67.00 | 12.00 | 260.00 | 380.00 | 710.00 | 230.00 | 2,700.00 |
| WR-GC-3A * | 4.00 | 22.00 | 91.00 | -8.70 | 34.00 | 24.00 | 18.00 | 240.00 | -7.50 | 3.80 | -130.00 | 19.00 | 11.00 | -3.80 | 770.00 | 7.60 | 38.00 | 20.00 | 340.00 | 29.00 | 1,300.00 | 1,300.00 | 1,500.00 | 3,400.00 | 1,300.00 | 13,000.00 |
| WR-GC-3B * | | | | | | | | | | | | | | | | | | | | | | | | | | |
| WR-GC-4 ** | 2.80 | 110.00 | 270.00 | 0.63 | 4.40 | 360.00 | 61.00 | 680.00 | 1.20 | 1.20 | 700.00 | 150.00 | 25.00 | 18.00 | 1,200.00 | 1.20 | 17.00 | 8.60 | 130.00 | 270.00 | 150.00 | 650.00 | 290.00 | 630.00 | 530.00 | 2,700.00 |
| WR-GC-5 * | 2.00 | 1.50 | 7.50 | -1.40 | 7.20 | -0.51 | -1.90 | 22.00 | 0.92 | 0.92 | 4.00 | -6.60 | -1.20 | -0.95 | 78.00 | 3.60 | 11.00 | 5.20 | 200.00 | 36.00 | -3.90 | 140.00 | 440.00 | 1,700.00 | 130.00 | 5,400.00 |
| WR-GC-6 * | 1.40 | 4.40 | 4.40 | -8.70 | ND | -6.90 | -6.30 | ND | -20.00 | ND | 14.00 | -10.00 | -18.00 | -24.00 | 51.00 | -16.00 | -21.00 | -7.60 | 78.00 | 26.00 | -6.60 | 26.00 | 180.00 | 220.00 | 7.90 | 1,700.00 |
| WR-GC-7 ** | 2.50 | 0.73 | 4.40 | -0.78 | 1.00 | -0.29 | -0.39 | 7.00 | -0.78 | 0.46 | 0.90 | -3.80 | 0.37 | -0.31 | 29.00 | 0.92 | 2.90 | 1.80 | 27.00 | 14.00 | 1.40 | 15.00 | 130.00 | 270.00 | 72.00 | 1,500.00 |
| WR-GC-7Rep ** | 2.00 | 3.50 | 13.00 | 0.62 | 4.50 | -0.99 | 0.77 | 18.00 | 1.30 | 1.30 | -3.80 | 1.40 | 1.50 | -0.37 | 52.00 | 2.00 | 11.00 | 7.10 | 89.00 | -1.80 | 77.00 | 77.00 | 200.00 | 410.00 | 110.00 | 1,800.00 |
| WR-GC-8 * | 0.90 | 2.30 | 4.70 | -0.72 | 2.70 | -0.98 | -0.72 | 5.90 | -1.30 | ND | 0.81 | -2.00 | -1.00 | -0.26 | 25.00 | 0.86 | 6.80 | 2.20 | 40.00 | 10.00 | -2.50 | 10.00 | 91.00 | 180.00 | 28.00 | 670.00 |
| WR-GC-9 * | 2.60 | 3.90 | 22.00 | -1.80 | 7.90 | -0.28 | -1.10 | 20.00 | 0.87 | 5.30 | 2.50 | 3.90 | 0.79 | -0.69 | 95.00 | 2.60 | 16.00 | 6.40 | 110.00 | 57.00 | 2.90 | 340.00 | 350.00 | 760.00 | 860.00 | 3,700.00 |
| WR-GC-10 ** | 3.10 | 4.50 | 15.00 | -1.30 | 3.00 | -0.97 | 0.59 | 20.00 | -1.50 | 1.40 | -4.50 | 1.20 | 1.20 | -0.49 | 47.00 | 2.40 | 17.00 | 6.80 | 110.00 | 19.00 | -2.20 | 64.00 | 160.00 | 310.00 | 69.00 | 1,200.00 |
| MINIMUM | 0.90 | 0.73 | 4.40 | 0.62 | 1.00 | 24.00 | 0.59 | 5.90 | 0.87 | 0.46 | 0.81 | 1.20 | 0.37 | 1.50 | 25.00 | 0.86 | 2.90 | 1.80 | 27.00 | 10.00 | 1.40 | 10.00 | 91.00 | 180.00 | 7.90 | 670.00 |
| MAXIMUM | 4.00 | 110.00 | 270.00 | 0.63 | 34.00 | 360.00 | 61.00 | 680.00 | 1.30 | 5.30 | 700.00 | 150.00 | 25.00 | 18.00 | 1200.00 | 7.60 | 38.00 | 20.00 | 340.00 | 270.00 | 1300.00 | 1300.00 | 1500.00 | 3400.00 | 1300.00 | 13000.00 |
| * METHOD BLANK | | 0.50 | 0.78 | -0.15 | ND | -0.16 | -0.06 | ND | -0.05 | ND | -0.09 | -0.16 | 0.29 | -0.10 | 0.29 | -0.17 | -0.12 | -0.20 | ND | -0.18 | -0.23 | ND | -0.51 | ND | -0.49 | 11.00 |
| ** METHOD BLANK | | -0.52 | ND | -0.26 | ND | 0.30 | 0.34 | 0.64 | -0.30 | ND | -0.36 | -0.35 | 0.78 | 0.69 | 1.50 | -0.38 | -0.38 | 0.61 | 0.61 | 0.82 | 1.50 | 2.30 | 2.10 | 2.10 | 4.50 | 8.50 |

NOTE: Negative numbers (-) indicate detection limits; ND indicates None Detected; asterisk (*) relates samples to corresponding Method Blank.

TABLE 4: Lower Columbia and Willamette River Sediment Sample Dioxin 1989 TEC'S (in pptr).

| SAMPLE SITE | 2378 TCDF | TOTAL TCDF | 2378 TCDD | TOTAL TCDD | 12378 PeCDF | 23478 PeCDF | TOTAL PeCDF | 12378 PeCDD | TOTAL PeCDD | 123478 HxCDF | 123678 HxCDF | 123789 HxCDF | 234678 HxCDF | TOTAL HxCDF | 123478 HxCDD | 123678 HxCDD | 123789 HxCDD | TOTAL HxCDD | 1234678 HpCDF | 1234789 HpCDF | TOTAL HpCDF | 1234678 HpCDD | TOTAL HpCDD | OCDF | OCDD |
|-----------------|-----------|------------|-----------|------------|-------------|-------------|-------------|-------------|-------------|--------------|--------------|--------------|--------------|-------------|--------------|--------------|--------------|-------------|---------------|---------------|-------------|---------------|-------------|-------|--------|
| 1989 TEFs | 0.10 | 0.00 | 1.00 | 0.00 | 0.05 | 0.50 | 0.00 | 0.50 | 0.00 | 0.10 | 0.10 | 0.10 | 0.10 | 0.00 | 0.10 | 0.10 | 0.10 | 0.00 | 0.01 | 0.01 | 0.00 | 0.01 | 0.00 | 0.001 | 0.001 |
| CR-GC-2 * | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.10 | 0.00 | 0.000 | 0.109 |
| CR-GC-4(EPA) | 0.03 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.03 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.03 | 0.00 | 0.001 | 0.014 |
| CR-GC-5** | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.01 | 0.00 | 0.000 | 0.003 |
| CR-GC-6 * | 0.15 | 0.00 | 0.00 | 0.00 | 0.21 | 1.80 | 0.00 | 1.90 | 0.00 | 0.45 | 0.38 | 0.38 | 0.42 | 0.00 | 0.45 | 0.35 | 0.23 | 0.00 | 0.05 | 0.06 | 0.00 | 0.07 | 0.00 | 0.015 | 0.043 |
| CR-VC-12A** | | | | | | | | | | | | | | | | | | | | | | | | | |
| CR-VC-12B** | 0.04 | 0.00 | 0.00 | 0.00 | 0.01 | 0.00 | 0.00 | 0.09 | 0.00 | 0.05 | 0.03 | 0.01 | 0.00 | 0.00 | 0.03 | 0.21 | 0.08 | 0.00 | 0.02 | 0.00 | 0.00 | 0.25 | 0.00 | 0.004 | 0.209 |
| CR-GC-15 * | 0.03 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.03 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.01 | 0.00 | 0.00 | 0.02 | 0.00 | 0.003 | 0.018 |
| CR-GC-16 * | 0.01 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.04 | 0.00 | 0.001 | 0.019 |
| CR-GC-17 * | | | | | | | | | | | | | | | | | | | | | | | | | |
| CR-GC-18 * | 0.06 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.02 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.04 | 0.00 | 0.002 | 0.042 |
| CR-GC-23** | | | | | | | | | | | | | | | | | | | | | | | | | |
| CR-GC-24** | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.02 | 0.00 | 0.000 | 0.000 |
| CR-GC-25** | | | | | | | | | | | | | | | | | | | | | | | | | |
| CR-GC-26** | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.03 | 0.00 | 0.001 | 0.034 |
| MINIMUM | 0.01 | 0.00 | 0.00 | 0.00 | 0.01 | 1.80 | 0.00 | 0.09 | 0.00 | 0.05 | 0.03 | 0.01 | 0.42 | 0.00 | 0.03 | 0.03 | 0.08 | 0.00 | 0.00 | 0.06 | 0.00 | 0.01 | 0.00 | 0.001 | 0.003 |
| MAXIMUM | 0.15 | 0.00 | 0.00 | 0.00 | 0.21 | 1.80 | 0.00 | 1.90 | 0.00 | 0.45 | 0.38 | 0.38 | 0.42 | 0.00 | 0.45 | 0.35 | 0.23 | 0.00 | 0.05 | 0.06 | 0.00 | 0.25 | 0.00 | 0.015 | 0.209 |
| WR-GC-2** | 1.85 | 0.00 | 0.00 | 0.00 | 1.20 | 5.00 | 0.00 | 0.00 | 0.00 | 0.00 | 1.10 | 0.40 | 0.15 | 0.00 | 0.27 | 2.10 | 1.10 | 0.00 | 0.67 | 0.12 | 0.00 | 3.80 | 0.00 | 0.230 | 2.689 |
| WR-GC-3A * | | | | | | | | | | | | | | | | | | | | | | | | | |
| WR-GC-3B * | 2.15 | 0.00 | 0.00 | 0.00 | 1.20 | 9.00 | 0.00 | 0.00 | 0.00 | 0.00 | 1.90 | 1.07 | 0.00 | 0.00 | 0.76 | 3.80 | 2.00 | 0.00 | 0.29 | 13.00 | 0.00 | 15.00 | 0.00 | 1.300 | 12.989 |
| WR-GC-4** | 10.95 | 0.00 | 0.63 | 0.00 | 18.00 | 30.50 | 0.00 | 0.60 | 0.00 | 70.00 | 15.00 | 2.47 | 1.80 | 0.00 | 0.12 | 1.70 | 0.86 | 0.00 | 2.70 | 1.50 | 0.00 | 2.90 | 0.00 | 0.530 | 2.689 |
| WR-GC-5 * | 0.10 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.46 | 0.00 | 0.40 | 0.00 | 0.00 | 0.00 | 0.00 | 0.36 | 1.10 | 0.52 | 0.00 | 0.36 | 0.00 | 0.00 | 4.40 | 0.00 | 0.130 | 5.389 |
| WR-GC-6 * | 0.39 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 1.40 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.26 | 0.00 | 0.00 | 1.80 | 0.00 | 0.008 | 1.689 |
| WR-GC-7** | 0.02 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.09 | 0.00 | 0.01 | 0.00 | 0.00 | 0.09 | 0.29 | 0.18 | 0.00 | 0.14 | 0.01 | 0.00 | 1.30 | 0.00 | 0.072 | 1.489 |
| WR-GC-7Rep** | 0.30 | 0.00 | 0.62 | 0.00 | 0.00 | 0.39 | 0.00 | 0.65 | 0.00 | 0.00 | 0.14 | 0.12 | 0.00 | 0.00 | 0.20 | 1.10 | 0.71 | 0.00 | 0.00 | 0.77 | 0.00 | 2.00 | 0.00 | 0.110 | 1.789 |
| WR-GC-8 * | 0.18 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.08 | 0.00 | 0.00 | 0.00 | 0.00 | 0.09 | 0.68 | 0.22 | 0.00 | 0.10 | 0.00 | 0.00 | 0.91 | 0.00 | 0.028 | 0.659 |
| WR-GC-9 * | 0.34 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.44 | 0.00 | 0.25 | 0.39 | 0.05 | 0.00 | 0.00 | 0.26 | 1.60 | 0.64 | 0.00 | 0.57 | 0.03 | 0.00 | 3.50 | 0.00 | 0.860 | 3.689 |
| WR-GC-10** | 0.40 | 0.00 | 0.00 | 0.00 | 0.00 | 0.30 | 0.00 | 0.00 | 0.00 | 0.00 | 0.12 | 0.09 | 0.00 | 0.00 | 0.24 | 1.70 | 0.68 | 0.00 | 0.19 | 0.00 | 0.00 | 1.60 | 0.00 | 0.069 | 1.189 |
| MINIMUM | 0.02 | 0.00 | 0.62 | 0.00 | 1.20 | 0.30 | 0.00 | 0.44 | 0.00 | 0.08 | 0.12 | 0.01 | 0.15 | 0.00 | 0.09 | 0.29 | 0.18 | 0.00 | 0.10 | 0.01 | 0.00 | 0.91 | 0.00 | 0.008 | 0.659 |
| MAXIMUM | 10.95 | 0.00 | 0.63 | 0.00 | 18.00 | 30.50 | 0.00 | 0.65 | 0.00 | 70.00 | 15.00 | 2.47 | 1.80 | 0.00 | 0.76 | 3.80 | 2.00 | 0.00 | 2.70 | 13.00 | 0.00 | 15.00 | 0.00 | 1.300 | 12.989 |
| * BLANK BATCH 1 | 0.05 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.03 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.000 | 0.011 |
| **BLANK BATCH 2 | 0.00 | 0.00 | 0.00 | 0.00 | 0.02 | 0.17 | 0.00 | 0.00 | 0.00 | 0.00 | 0.00 | 0.08 | 0.07 | 0.00 | 0.00 | 0.00 | 0.06 | 0.00 | 0.01 | 0.02 | 0.00 | 0.02 | 0.00 | 0.005 | 0.009 |

NOTE: Asterisk (*) relates samples to corresponding Method Blank.